

Special automotive tools

513 Adaptor

1/2" socket x 3/8" plug.



Code	Type	 g	
13 03 00 02	BMW: series 3, 518, 520	55	5

1417 BIT

for inside TORX® screws, size T25; 1/4" -drive, for screws on sun roof E30.



Code	Type	 g	
08 13 00 25	BMW	6	10

3054X-M10 Screwdriver BIT

for tri-square socket head screws (XZN®), size M10, on drive shaft bolts.



Code	Type	 g	
03 26 14 10	Mercedes-Benz	142	5

11060-3 Internal puller

capacity 27-36 mm, for taper roller bearing outer ring on steering housing, to be used with counter stay No 11061-2.



Code	Type	 g	
71 16 00 13	Mercedes-Benz	365	1

11061-2 Counter stay with reduction unit

for taper roller bearing outer ring on steering housing.



Code	Type	 g	
71 17 00 12	Mercedes-Benz	1500	1

46-19 Socket

Fiat-No A 57 052 extra deep, bi-hexagon, size 19 mm, 3/8" -drive, for front mounting screw of top steering link on front wheel suspension.



Code	Type	 g	
02 02 00 19	Fiat: 1500, 125	112	10

12495 Brass punch

Ø 20 mm, length 200 mm, for use on bushes bearing rings, steering pivot pin.



Code	Type	 g	
77 13 00 00	VW/Audi	533	5

Special tools for ignition and electrics

3466 Spark plug socket

3/8" -drive, with magnet, outside dia 25.5 mm, for deep seated plugs.



Code	 mm/"	L mm	 g	
02 14 00 36	16-5/8	85	198	5

4600 Spark plug socket

3/8" -drive, with rubber insert.



Code	 mm/"	L mm	 g	
02 12 00 36	16-5/8	60	88	10

4606 Spark plug socket

3/8" -drive, with rubber insert.



Code	 mm/"	L mm	 g	
02 13 00 18	18-11/16	65	132	10

46 Spark plug socket

3/8" -drive, with rubber insert.



Code	 mm/"	L mm	 g	
02 02 02 08	20,8-13/16	65	151	10

51 Spark plug socket

1/2" -drive, with rubber insert.



Code	 mm/"	L mm	 g	
03 02 02 16	16-5/8	83	137	10
03 02 02 08	20,8-13/16	83	194	10