

Special tools for chassies and steering

40TX-E8 Socket

HPQ

- for external TORX® screws, size E8
- 1/4" -drive
- for steering lock screws



Code	Type		
01 27 00 08	BMW	10 g	10

24-17x19 OPEN-Ring spanner

AS

- bi-hexagon, 17 x 19 mm
- use on wingpump manifold (hydro-steering)



Code	Type		
41 08 17 19	BMW	150 g	10

55-36 Socket

AS HPQ

- hexagon, 36 mm
- 3/4" -drive
- use on vibration damper



Code	Type		
05 01 00 36	BMW: series 5, 6 and 7, except 518-520i	386 g	2

11060-3 Internal puller

- capacity 27-36mm
- for taper roller bearing outer ring on steering housing
- to be used with counter stay No 11061-2



Code	Type		
71 16 00 13	Mercedes-Benz	365 g	1

11061-2 Counter stay with reduction unit

- for taper roller bearing outer ring on steering housing



Code	Type		
71 17 00 12	Mercedes-Benz	1518 g	1

540-22 CROW-FOOT spanner

- 22 mm
- 3/8" -drive
- use on track-rod



Code	Type		
02 20 00 22	BMW: series 3, 518, 520	64 g	1

513 Reducing adaptor

HPQ

- 1/2" socket x 3/8" plug



Code	Type		
13 03 00 02	BMW: series 3, 518, 520	60 g	5

1417 Bit

- for inside TORX® screws, size T25
- 1/4" -drive
- for screws on sunroof E30



Code	Type		
08 13 00 25	BMW	6 g	10

3054X-M10 Screwdriver socket

- for tri-square socket head screws (XZN®), size M10
- on drive shaft bolts



Code	Type		
03 26 14 10	Mercedes-Benz	142 g	5

46-19 Socket

AS HPQ

- Fiat-No A 57 052
- bi-hexagon, 19 mm
- 3/8" -drive
- for front mounting screw of top steering link on front wheel suspension



Code	Type		
02 02 00 19	Fiat: 1500, 125	112 g	10

12495 Brass punch

- Ø 20 mm, length 200 mm
- for use on bushes bearing rings
- steering pivot pin



Code	Type		
77 13 00 00		533 g	5